



PERFORMANCE BY
**INTEGRATED
ENGINEERING**

IE B8 SQ5 HPFP (High Pressure Fuel Pump) Install Guide
IE Part Numbers: IEFUVJ1

Thank you for purchasing another high-quality Integrated Engineering product! This instruction guide is used for the installation of IE's HPFP Upgrade Internal Kit for Audi B8/B8.5 S4/S5/SQ5 and C7 3.0T TFSI engines. Installation requires disconnection of fuel lines, bench vice, and a very clean working environment. Professional or experienced technician installation is highly recommended. Integrated Engineering is not responsible for any damage or premature wear on fuel pump internals caused by incorrect installation.

KIT CONTENTS:

- IE High Pressure Fuel Pump




TOOLS REQUIRED:

- T25 Driver
- Flat Head Screwdriver
- 10mm Socket
- T30 Driver
- #10 Triple Square Driver
- 17mm Open Ended Wrench
- Pliers

Before you begin, park your vehicle in a safe and level location. Allow plenty of time for the engine to completely cool before beginning the installation procedure. Unbox your IE HPFP Kit to verify the contents and quantities and check for any possible shipping damage. Prepare your work space and locate the required tools listed above before starting.

IE recommends pre-reading the entire installation guide ahead of your install to both prepare yourself for each step and to make sure you don't have any questions before beginning. If you have any questions or need clarification, please contact our helpful support team specialists at support@performancebyie.com

Locate the six Press In Retainers located on the plastic bumper cover.



Remove the retainers by first pushing in the middle,




Then popping it out of its socket with a flat head screwdriver.



Once all 6 retainers have been removed, remove the front bumper cover from the engine bay.



Remove two T25 screws from each side of the air inlet.



Remove the air inlet from the engine bay by pulling straight away from the airbox



Remove the fuel line located on the top of the intake by unclipping the retainer.



Remove clamps from the intake hose by pushing down on top of the clip and pulling away.




Remove the secondary air inlet by squeezing release tabs, then pulling away from the airbox.



Remove the airbox by lifting it straight up and out of the engine bay.




Remove two 10mm nuts from the HPFP housing.




Remove shield from the HPFP housing.




Remove the T30 screw from the top of the HPFP housing.




Place a rag around the line to catch any fuel, then slowly loosen the 17MM nut from the high pressure fuel line.




Using pliers, squeeze the clamp on the low pressure fuel line then remove the line from the fuel pump.



Remove two #10 triple square screws from the pump housing. One above pump and one below.



Remove both sensors from housing by pinching release tabs and pulling away.



Reinstall New IE HPFP in reverse order of removal.

Once reinstallation of the new IE pump is complete, you'll want to prime your new pump. This can be done by either cycling the key to position 2 (Pressing the start button without a foot on the brake) or by simply locking and unlocking the vehicle. This is also the ideal time to check for leaks from any hoses or seals.



Thank you for purchasing another Integrated Engineering product. We are dedicated to serving your VW/Audi engine and performance needs. Please check our website frequently for new product releases. If you have any questions or concerns about this product please do not hesitate to contact us.

Integrated Engineering
801.484.2021
sales@performancebyie.com
www.performancebyie.com

PERFORMANCE BY

