

Xodus



INSTALLATION GUIDE

Xodus Cold Air Intake System For 2015-2026 Ford Raptor & F150 Ecoboost

X0INFA1 + X0INFA2

Help@DriveXodus.com

[DriveXodus.com](https://www.DriveXodus.com)



This installation guide is for instructional purposes only. For best results, professional installation by an experienced technician is always recommended. By reading this guide you agree Integrated Engineering is not responsible for any damage caused by incorrect installation.

DIFFICULTY



Expect 30 - 40 minutes on average

REQUIRED PARTS

- No additional parts are required for this install

REQUIRED TOOLS

- Flathead screwdriver
- 7mm Socket or wrench
- 13mm Socket

BEFORE YOU BEGIN

It is highly recommended to pre-read this entire guide ahead of your installation to familiarize yourself with each step. Always park your vehicle in a safe and level location and allow plenty of time for the engine bay and exhaust to completely cool. Locate and prepare your work space with each required tool listed above. Unbox all components and verify the contents and quantities before you begin. If anything is missing or damaged, please contact us for immediate help at help@drivexodus.com

SPECIAL NOTE:


This install guide has been photographed and written on a 2019 Ford F-150 Raptor. Some steps and factory hardware specifications may vary depending on vehicle model, year, and region. This guide is for reference purposes only. If you are unsure of the installation procedure for any individual step or part, please seek professional help before proceeding.

INCLUDED PARTS

- | | |
|---------------------------------|---|
| 01 - F150 INTAKE BOX | 09 - WORM-DRIVE CLAMP 3-9/16" TO 4-1/2" |
| 02 - INTAKE LID | 10 - WORM-DRIVE CLAMP 2-13/16" TO 3-3/4" (5X) |
| 03 - BELLMOUTH | 11 - NYLON PUSH RIVET (2X) |
| 04 - INTAKE AIR FILTER | 12 - POINTED SCREW FOR PLASTIC (4X) |
| 05 - DRIVER SIDE INTAKE TUBE | 13 - M6 WASHER (2X) |
| 06 - PASS. SIDE INTAKE TUBE | 14 - M6 BUTTONHEAD SCREW (2X) |
| 07 - DRIVER INTAKE TUBE COUPLER | 15 - RUBBER GROMMET |
| 08 - PASS. INTAKE TUBE COUPLER | 16 - TWO-PC PUSH-IN RIVETS (8X) |

Some items may be partially assembled.

1




Using a flathead screwdriver or 7mm socket or wrench, loosen hose clamps on factory turbo inlet pipes.

2




Release coolant hose from lower turbo inlet pipe.

3




Unplug IAT sensor from intake pipe.

4




Using a 13mm socket, remove bolt from intake mount.

5




Remove two push clips at intake inlet.

6




Remove intake pipe clamp using a flathead screwdriver or 7mm socket or wrench.

7




Remove stock intake box from vehicle by pulling up to release from push grommets.

8




Remove stock intake pipe from vehicle.

9



Remove sensor from intake pipe by twisting 90° and pulling sensor out.

10



Install sensor onto Xodus intake pipe (XOINFA2-1) by aligning channels and rotating 90° clockwise.

11



Install intake pipes into intake box by lining up the notches. The intake pipe with the sensor should be on the passenger side of the vehicle when installed.

12



Install included hose clamps onto Xodus intake bellmouth (XOINFA1-3.)

13



Install bellmouth into Xodus intake box. Make sure previously installed clamps are in an accessible location. Tighten clamps as assure that bellmouth and intake pipes are secured to each other.

14




Install included intake filter into intake box and onto bellmouth. Tighten using a flathead screwdriver.

15




Install a hose clamp onto silicone coupler (XOINFA1-8) and install onto driver side intake pipe.

16



Install a hose clamp onto silicone coupler (XOINFA1-7) and install onto passenger side intake pipe.

17



Remove mounting grommet from stock intake by removing sleeve from grommet.

18




Install previously removed grommet onto Xodus intake box.

19



Place Xodus intake into engine bay and push down to seat into place in factory grommets.

20




Install hose clamps onto previously installed couplers and attach to factory turbo inlet pipes. Tighten using a flathead screwdriver.

21



install mounting bolt into previously installed grommet and tighten using a 13mm socket.

22




Reinstall inlet press clips.

22



Plug in IAT sensor.

24



Install intake lid by pressing down and seating into place.



ENJOY!

Thank you for purchasing an Integrated Engineering product. We are dedicated to serving your performance needs. Please check our website frequently for new product releases. If you have any questions or concerns about this product please do not hesitate to contact us.

Xodus

+1 (833) 985 7050

WWW.DRIVEXODUS.COM

Help@DriveXodus.com

